


## Criocabin Display Refrigeration Operating Instructions

To the rear of each counter section there is a Carel control panel and digital temperature display. The control panel has eight buttons, as shown below:



### To turn on or off:

Press and hold button 3 for approximately 5 seconds.

### To turn lighting on or off:

Press button 2.

### To adjust set temperature:

Press and hold button 8 for approximately one second. "St" will appear on display. Press button 8 again and the cabinet set temperature will appear. This can now be adjusted upwards by pressing button 6, or downwards by pressing button 7. When the display shows the set temperature you require, press and hold button 8 again for approximately 5 seconds. The new set temperature will then be held in the controller's memory.

**Note.** The cabinet set temperature is the temperature at which the compressor will cut out. The temperature in the cabinet will then be allowed to rise by 2°C, before the compressor starts up again. Hence with a set temperature of 2.0°C, the actual display temperature will cycle between 2°C & 4°C

When the compressor is running button 6 will be illuminated.

When the cabinet goes on to its defrost cycle, button 7 will be illuminated. In normal conditions the cabinets are set to defrost every 6 hours. The length of the defrost period depends upon the amount of ice built up around the coil, but will normally last for no more than 15 minutes. In unusual environmental conditions slightly different defrost times may be set, but we would recommend this is only done by a refrigeration engineer.

A forced manual defrost can be set if ice remains around your evaporator from unusual circumstances. Press and hold button 7 to start an manual defrost at any time.

For standard cabinet operation, buttons 1, 4 and 5 are NOT used.

For further information regarding the operation of your Criocabin refrigeration, please contact:

**Creative Retail Solutions Ltd** 01202 233088

## Refrigeration Service & Maintenance

To ensure efficient operation of your equipment and to meet **warranty conditions** it is important that:

- All air ducts and ventilation grills are kept clear and unobstructed.
- Condenser and evaporator grills are cleaned regularly (weekly) of debris with a stiff brush or vacuum cleaner.
- Drain filters are cleaned regularly (weekly) to keep water flowing.
- Temperatures are monitored so that any problem is spotted early.
- Equipment is serviced by a qualified engineer at six monthly intervals.

In common with all electromechanical equipment the efficiency and lifetime will be significantly enhanced with proper maintenance and servicing.

We recommend that servicing should be done on a six monthly basis to ensure the equipment is operating correctly. Servicing must be done by ourselves or by your own qualified refrigeration engineer. Prolonged operating without servicing will reduce the life of major components.

During the warranty period please keep all engineers worksheets. In the event of a warranty claim we will require a copy to ascertain what work has been done to your equipment during the warranty period.

We offer highly competitive rates for service and repairs for all refrigeration and air conditioning equipment. Should you experience any problems with your equipment or require a quotation for service or maintenance to equipment, then please contact us on the numbers below:

Sales Office - Creative Retail Solutions Ltd	<b>01202 233088</b>
--	---------------------

Service Office - RSR Ltd	<b>01202 876010</b>
--------------------------	---------------------

Out of hours Emergency service	<b>07623 978850</b>
--------------------------------	---------------------

**Creative Retail Solutions Ltd.** 33 Queens Park Drive South, Bournemouth, Dorset, BH8 9BH  
Tel 01202 233088 Fax 01202 304113 Email [sales@creativeretailsolutions.co.uk](mailto:sales@creativeretailsolutions.co.uk)  
Vat No: 812 0898 36 Company registration 4677049